

AirBench™ FPW



Operation and Maintenance

This Edition: 16 May 22

AirBench Ltd, 6b Commerce Way, Colchester CO2 8HR

www.airbench.com

+44 (0) 1206 791191

Cautions	3
Introduction	4
OVERVIEW	4
ABOUT AIRBENCH	4
ABOUT THIS DOCUMENT	4
Installation	5
GENERAL	5
ELECTRICAL	5
DUCTED UNITS	5
ASSEMBLY OF ACCESSORIES	5
Commissioning	7
GENERAL	7
IN HOUSE COMMISSIONING	7
FUME EXTRACTION UNITS	7
Operation	8
PRIOR TO USE	8
GENERAL USE	8
WELDING	9
Maintenance	10
FILTER CARE	10
SPARES	13
OTHER ROUTINE MAINTENANCE	14
Accessories	15
FILTER PRESSURE GAUGES	15
HOURS RUN METER	15
WHEELS	15
COMPRESSED AIR INTERLINK	15
Thorough Examination and Testing	16
Technical	17
ARRANGEMENT	17
TECHNICAL DATA	17
Declaration of Conformity	18

CAUTIONS



Use the AirBench only for the designed duty – consult the manufacturer on any change of use.

Each unit is marked with its design application, which is also shown on the commissioning certificate.



The filters are not self-cleaning.

They must be maintained / cleaned / replaced as described within.



Do not mix incompatible materials e.g. steel and aluminium.

It is the users' responsibility to comply with this legal requirement.



This unit is not ATEX rated.

It is your responsibility under ATEX regulations to ensure the AirBench is located in an area rated suitable for the specification of the AirBench.



Do not work coated or galvanised materials on this unit, or introduce flammable dusts. Use only for mild steel dust and/or weld fume.

INTRODUCTION

Overview

Thank you for choosing AirBench as your fume or dust control system. Please read this document before installation and use.

This document details maintenance activities which are essential to the safe use of your AirBench. We recommend that the Responsible Person reads this manual fully prior to installation and operation of the AirBench.

This document refers to the AirBench FPW type. Models of this type are available with a range of filter configurations. The filter configuration in use is detailed on the system Commissioning Certificate and is used within this document to provide filter-specific maintenance information.

About AirBench

AirBench is a self-contained down draught extraction bench which utilises a fan and filter combination selected for your specific application, to extract and filter dust/fumes and return filtered air to the work place.

Some models vary in filtration and filtered air delivery point.

It is used by running the fan at either fixed speed or variable speed (if speed controller fitted) to draw the pollutant down and through the filters, allowing the process to proceed on the surface.

About this Document

This document provides general maintenance and operation instructions for the AirBench FPW range. It should be read in conjunction with the Commissioning Certificate supplied with the unit. If you have any concerns or doubts about maintenance or operation of this unit, contact the manufacturer.

INSTALLATION

General

Unpack the unit and check for damage, if not already completed.

The AirBench must be installed on a flat and level floor capable of carrying the weight of the unit. For nominal unit weights, see Specifications section at rear of manual. When determining an installation location, be aware that the air exhaust must discharge somewhere. Do not position the unit so all outlets are blocked.

These models are designed to be moved into place using a forklift or pallet truck, taking care not to damage fittings on the base of the unit.

Please note installation may be required when using certain accessories, external fansets, or ducting (see below).

After shipment, filters may be dislodged. Always check prefilters (in main body of bench) and final filter (in side table) prior to first use.

Electrical

WIRING

AirBench is supplied as standard with an internal fan or fans. These are pre-wired to a switch or speed controller and fitted with a lead and plug for your convenience. Standard electrical supply is 240V/1Ph/50Hz. Certain models can be supplied with 110V/1Ph/50Hz internal fans if specified in advance; this is noted on the front left of each unit where applicable.

BS7671 requires that the lead is appropriate for the working environment and you must satisfy yourself that the pre fitted lead is satisfactory.

FUSES

Switched units: A fuse is provided on the switch front plate.

Speed controlled units: An additional fuse is provided within the speed control panel. To check this fuse, remove the service panel; the speed control panel is mounted on the rear of the service panel.

PAT TESTING

FPW Model AirBenches use EC (electrically commutated) fans. EC fans may give misleading readings when PAT Testing, particularly if using a battery powered tester. These units should be tested by a qualified electrician using a mains-fed PAT Testing device.

Ducted Units

This unit is not suitable for connection to ducting.

Assembly of Accessories

These items apply only when they have been ordered with the AirBench.

ENCLOSURE

Enclosures are supplied fully assembled where possible. Where shipping does not permit assembly prior to dispatch, enclosures should be assembled as follows using bolts supplied:

- Loosely fit left and right panels to left and right frame of bench.
- Loosely fit rear panel with assistance if required.
- Lay top panel (if supplied) on top of enclosure and bolt into position.
- Tighten all bolts.

COMMISSIONING

General

The initial commissioning and testing of your AirBench has been performed prior to delivery. However, as part of in-house commissioning we recommend that you complete the following tasks and record the results as appropriate in the system logbook.

In House Commissioning

The following tasks should be completed by a responsible person; for example, the Health and Safety Officer, or Director, responsible for this process.

- Review the commissioning certificate for this unit, in particular any notes made by our engineer in relation to use.
- Ensure all operators are trained to use this machine and are aware of the effective capture zone in which they should aim to work.
- Ensure all operators are aware of the filter maintenance routine required for this machine.

Once complete, you should note this on the commissioning certificate and retain the certificate for future reference.

As operating conditions vary, each installation will vary in maintenance needs and this is best established by empirical means, regularly checking filter condition in the first weeks of operation to establish a procedure. Reduced airflow is a key indication of filter condition. If the filter pressure gauge on the front of the unit is showing in the red zone, this indicates low airflow and filters should be checked and cleaned or changed promptly, according to the instructions contained within this manual.

We recommend keeping the commissioning certificate, Quick Start guide, and logbook with the machine at all times for operator access.

If in doubt please contact the manufacturer quoting the machine serial number.

Fume Extraction Units

The effectiveness of carbon filtration improves as airspeed is lowered allowing fumes to spend longer passing through the filters. A speed controller is supplied with carbon filtered units to allow airflow to be adjusted to the optimum level.

We therefore recommend adjusting the speed controller provided to the lowest level at which extraction is still effective and marking this operation point on the speed controller. Ongoing adjustment may be required as filters become blocked with use.

OPERATION

This page contains the same information as the Quick Start guide provided with your AirBench.

Prior to use

Check the system logbook to ensure no routine maintenance is required.

General use

To use AirBench, ensure it is plugged in to a mains socket and the socket is switched on. Turn on the switch on the front of the bench.

If a speed controller is fitted, turn it to full power before switching on, then adjust it to an appropriate level. Our recommended settings are shown below:

Fume: 50-75%

Light dusts, 50-100%

Heavy dusts, 75-100%

During commissioning, an optimum setting may have been determined and this should be noted in the system logbook.

Check the filter pressure gauge on the front of the bench. If the needle on the gauge is showing within the RED zone, check the filter condition – they may require cleaning or replacement.

Your AirBench has a zone above the surface in which capture is most effective, in a straight line upwards from the ventilated area. The extent of this zone is detailed in the commissioning certificate supplied with the unit. This zone forms a box in which you should aim to do the majority of your work. Working outside this zone may reduce the effectiveness of the extraction.

Work as normal, aiming to work within the extraction zone described above. On completion of work, switch the AirBench off using the switch on the front. Record any maintenance you have undertaken, or any that is required, in the logbook.



To avoid fan overload, do not block more than 95% of the work surface or the air outlet.

Welding

Depending on filter configuration, AirBench FPW may be supplied for welding. It is important to correctly connect the earth clamp from your welder to the workpiece to avoid damage to the electrical components of the AirBench.

You should ensure that you are not relying on earth connections via painted components. AirBench surfaces, as standard, are not designed as earthing points for welders; if uses for this purpose the surface should be unpainted, with a good connection to the earthing cable and to the workpiece.

If in doubt, contact us.

Grinding

Depending on filter configuration, AirBench FPW may be supplied for grinding. If used for grinding, it is important that flammable dusts are not introduced to the unit. Do not grind paint, galvanizing coatings, or other materials into the unit. Do not grind aluminium dust into the unit as this is a significant fire risk.

MAINTENANCE

Filter care

The filters are not self-cleaning and must be maintained / cleaned / replaced as described below. Proper filter care is essential for the effective operation of your AirBench. If in doubt, contact the manufacturer for advice.

When changing filters, the seals on which the filters sit should be checked for damage and replaced if necessary.

All filters should be regularly checked for wear, damage, or by-passing.

When completing filter maintenance activities these should be recorded in the accompanying log sheet.



Take precautions and wear appropriate PPE when handling filters.

They may contain hazardous dusts.




If using a vacuum cleaner to empty filters, excessive cleaning will reduce filter life.


Remove excess dust only.

FILTER ACCESS

Prefilters are accessed by removing the top surface, taking care as the surface may have sharp edges. Once the surface is removed, a retaining plate is exposed which holds the prefilters vertically in place. This can be lifted out and filters rotated forwards for access as per the following diagram.



The main filter is accessed via the door on the filter housing (to the left of the main unit). This can be opened by rotating the quarter turn latch and swinging the door forward. Once the door is open, a clamp bar is exposed which holds the filter in position against soft rubber seals. The clamp bar can be loosened, allowing the main filter to rotate forwards and be removed as per the following diagram.





Surfaces can be heavy and have sharp edges.

Wear appropriate hand protection.

LABYRINTH FILTERS



Labyrinth filters consist of a series of metal channels, in a metal frame.

These filters can be emptied regularly using a vacuum cleaner by lifting the surface of the AirBench. They can also be removed and emptied.

In general labyrinth filters do not require replacement except when damaged.

DISPOSABLE MEDIA PADS



Media pads are green and white fibreglass pads, held in a metal frame.

These filters are not cleanable. When replacing, the frame and clip which hold the pad can be reused. Always replace with white side downwards.

Replace on a monthly basis, or more regularly if required.

WELDING / FETTLING PLEATS



Welding / fettling pleats consist of large, 300mm deep arrays of fine paper pleats, in a plastic case.

This filter is not cleanable.

Replace the filter when it is stained on the clean (outlet) side or damaged.



Do not clean filters using compressed air.

This will damage media and spread dust.

Spares

See the specific list for your machine shown on the commissioning certificate.

When ordering, please contact the manufacturer quoting the serial number of this machine.

Other routine maintenance

We recommend the following tasks be performed on a regular basis. Suggested intervals are shown and these should be reviewed dependent on level of use. Actual completion of these operations and any variation to these recommended maintenance intervals should be recorded in the system logbook.

If completion of routine maintenance tasks suggests additional issues, contact the manufacturer for advice.

FILTER SEALS

These sit behind the filters and prevent dust passing into the body of the bench and the exhaust airstream. It is important the seals are in good order. Check the condition of the filter seals every time filters are changed or removed.

SURFACE

At least monthly, or as routine, check the surface condition. Clear any blocked holes.

FAN CHAMBER

At least every 6 months, check the fan chamber. Remove any debris and clean.

FAN

At least annually, check and tighten fan fixings, impeller fixings, and electrical connections.

ACCESSORIES

Some accessories are only supplied if specified with purchase.

Filter Pressure Gauges

A filter pressure gauge is fitted as standard to the front of each AirBench. This indicates performance of the unit as a whole, and filter condition. Certain models show a red zone on the filter gauge; when the gauge indicates within this zone, filters may be blocked or require cleaning. Turn the AirBench off and inspect the filters.

Where no red zone is shown, a filter inspection pressure drop will be recorded on the Commissioning Certificate. When pressure loss is greater than that shown on the Commissioning Certificate, follow the above procedure.

A high pressure reading may also indicate a blocked surface. Inspect the surface for blockages and clean if required. Do not operate AirBench continuously with more than 75% of the surface blocked.

Hours Run Meter

The meter is not resettable and operates at all times when the speed control or switch is powered.

Wheels

Standard industrial rubber wheeled swivel castors are used. The two front wheels are lockable. Lock by pressing on the lever and trip by flicking (models and operation vary slightly). Do not attempt to move while brakes are on.

Compressed Air Interlink

This option ensures the safety of operators by preventing the use of air tools without extraction being operational; and reduces energy use by switching off the fan after 5 minutes of non-use.

4 off series 19 airline connectors are provided to the front or side of the unit and an internal timer fitted, pre-set to an agreed value – usually 5 minutes. The control panel is supplied with an additional Red / Green push-button.

System control will be as follows:

Switch main on/off switch to On – system is energized. Airline is switched to operational.

Press green button – fan starts and runs for 5 minutes.

Use airline or press green button again – timer is reset for a further 5 minutes.

Press red button – fan stops, airline stops.

The timer can be re-set to a different interval; contact the manufacturer for details.

THOROUGH EXAMINATION AND TESTING

If AirBench is used as an LEV system it must be tested at regular intervals, as specified below, and certificated under the COSHH regulations. This service is available from us, or our approved testers.

Thorough examination and test should include:

- Ensuring the prescribed maintenance routines are being completed and recorded within the system logbook.
- Condition check of fan, filters, electrics.
- Performance testing according to recommended face velocities.
- Visual check that operators are working within effective area.
- Visual check of effectiveness using, for example, smoke tubes.

Statutory test intervals are:

Process	Minimum Frequency
Jute cloth manufacture	1 Month
Processes in which blasting is carried out in or incidental to the cleaning of metal castings, in connection with their manufacture	1 Month
Processes, other than wet processes, in which metal articles (other than of gold, platinum or iridium) are ground, abraded or polished using mechanical power, in any room for more than 12 hours in any week	6 Months
Processes giving off dust or fume in which nonferrous metal castings are produced	6 Months
All other processes	14 Months

Recommended face velocities are as follows:

Fume control: Minimum 0.5m/s

Light dust control: Minimum 1.0 m/s

Heavy dust control: 1.2 – 1.5m/s

Completion of Thorough Examination and Testing should be recorded within the system logbook.

TECHNICAL

Arrangement




Service Panel



Body



Filter monitoring



Prefilters



Main filter



Fan



Prefilter access



Surface
In multiple sections on 960 deep units.



Main filter access

Technical Data

Model	Width (mm)	Depth (mm)	Height (mm)	Weight (kg)	Fan Power (kw)	Max Current (a)
FPW209084	1950	960	840	160	0.86	4.4
FPT209084	1950	960	840	160	0.86	4.4

Data shown is for standard models. Check the Commissioning Certificate for details specific to your unit.

DECLARATION OF CONFORMITY

Manufactured by:	AirBench Ltd. 6b Commerce Way, Colchester, Essex. CO2 8HR
Responsible Person:	Simon Cook
Description:	Ventilated work bench known as "AirBench"

DECLARATION OF CONFORMITY

BY AIRBENCH LIMITED

RELEVANT DIRECTIVES

EMC Directive 2014/30/EU (when connected to standard mains sinusoidal supply).

Machinery Directive 2006/42/EC

Low voltage Directive 2014/35/EU

- EN-60204-1:2018 (Safety of machinery, electrical equipment of machines, general requirements).

- EN-60335-2-80 (Safety requirements for electric fans and regulators).

We; AIRBENCH Limited, declare that "AirBenches" when supplied as self contained equipment comply with the directives detailed above and therefore comply with requirements of the Low Voltage Directive.



Simon Cook / Managing Director / 5th March 2021

Data shown is for standard models. Check the Commissioning Certificate for details specific to your unit.